





Huge range of sizes from A4 to 24 x 36".



Eyecatching display



Studs hold it off the wall



Works portrait or landscape



## Visionwall - Acrylic Wall Display

### Unique, stylish and fast - this is a market leader!

- Easy to create - no holes to cut
- Easy to hang - one centre point
- Portrait or landscape
- Transform assembly speeds and no equipment required
- Studs position it away from wall
- Change your image at any point
- Patent pending

30 SECS TO MAKE  MADE IN UK

### Sizes available:

10 x 15" VW1015	12 x 16" VW1216	12 x 18" VW1218	16 x 20" VW1620	18 x 24" VW1824
20 x 30" VW2030	594 x 420 mm VWO2	210 x 297 mm VWO4	297 x 420 mm VWO3	

### How to insert your own picture...



Push metal button into black studs, then insert black studs into back of board.



Clip the hanger in place, portrait or landscape.




Turn over and position picture. Lay acrylic on top and drop the 4 magnets into the holes.



Finished - ready to display!

# Vision Wall Art Instructions



ashgrove

PRESENTATION - PACKAGING  
PAPER - PRINT FINISHING

## Contents

1 x Back board	4 x Round nylon 'Stand-offs'
1 x Clear acrylic cover	4 x Metal inserts
1 x Wall hanging tab	4 x Polished magnets

## Key Benefits

- Patent pending
- Easy & fast to create then wall hang
- Interchangeable - option to refresh image
- Contemporary borderless design



1  
Push the metal inserts into the nylon (plastic) stand-offs.



2  
Place the back board **PICTURE SIDE DOWN**. Insert the stand-offs in to the back of the black back board, and spin to click in place.



3  
Slide in the wall hanging tab, with picture side down, until it locks into position, either portrait or landscape as required.



4  
Assembly over, turn picture side up, place your print over the front of the backboard. Maximum paper thickness 250.micron.



5  
Remove protective film from both sides of the acrylic, align the print and acrylic by pinching the two opposite corners.



6  
Drop the polished magnets into place - **WARNING POWERFUL MAGNETS**. Display Note: Always ensure you hang onto a secure wall fixing.